

## What's in the box?

---

- (1) Dreamweaver Sound Soother
- (1) Charging Cable

## Getting started


---

### 1. CHARGE THE DREAMWEAVER


Before you start using the Dreamweaver for the first time, it's a good idea to charge it completely.


**To charge the Dreamweaver:**  
Open the DC IN flap on the back of the Dreamweaver.

Plug the included charging cable into the jack behind this flap. Plug the other end into a power source, like a computer or a USB charging adapter. The indicator above this jack turns red to show the Dreamweaver is charging.



### 2. TURN ON THE DREAMWEAVER

Press and hold the  button on the back of the Dreamweaver.






## Everyday use


---


### PLAYING SOUNDS

The Project Nursery Dreamweaver offers a variety of soothing lullabies and nature sounds, as well as white noise, to calm baby.

**To cycle through these sounds:**  
Press the  button on the back of the Dreamweaver. Each press goes to a different selection.

**To adjust the volume:** Press the  or  button.

**To turn sounds off:** Press and hold the  button on the back of the Dreamweaver. (If lights are on, they remain on.)




## USING THE TIMER

The timer shuts the lights and sound off automatically after a set amount of time.

**To set the timer:** Press the ⌚ button on the back of the Dreamweaver.

The minutes indicator on the back of the Dreamweaver shows the amount of time on the timer: **15**, **30**, **45**, or **60** minutes.

Press ⌚ to cycle through these options or turn the timer off.



## USING THE NIGHTLIGHT


The Dreamweaver offers four kinds of fun, firefly light modes.

**To turn the light on:** Press the 💡 button on the back of the projector.

**To change light modes or turn off the light:** Press the 💡 button repeatedly to cycle through the modes (fade, sparkle, dance, and rhythm) and to turn the light off.

**TIP:** You can use the nightlight even if the Dreamweaver is turned off. Just press the 💡 button!

Back of the Dreamweaver



project nursery®

**DREAMWEAVER**  
LIGHT & SOUND SOOTHER

Quick Start Guide

Questions?

Visit [ProjectNursery.com](https://ProjectNursery.com) for setup videos and support.