



SANITIZE ANYTHING

LET'S **GET STARTED** 

1 Plug in




Plug the power adapter into the power jack on the bottom of the XL Pro.



Run the power cable through the canal on the bottom of the XL Pro.

Plug the power adapter into an outlet or surge protector.


2 Load up




Open the cover of the XL Pro. Then place the items you want to sanitize inside.

Charge up, too!



The XL Pro charges up to 3 mobile devices at a time. Just plug your charging cables (not included) into the charging ports inside the XL Pro. The indicator lights below these ports light red while charging and green when your device is charged.




3 Sanitize!





Close the cover and choose the sanitization cycle you want to use.


For these items	Use this cycle	To start:
Hard, non-porous (like phones, tablets, watches and remote controls)	Standard cycle (around 10 minutes)	Press the  button.
Fabric and soft porous (like facemasks, toothbrushes, and makeup brushes)	Deep clean cycle (around 20 minutes)	Press and hold the  button until it flashes twice.

The  button turns blue during sanitization. It turns off when the sanitization cycle is complete.

Notes:


- The  button flashes red if the XL Pro's cover is open when you try to start sanitization. For your safety, the XL Pro cannot proceed with sanitization if the cover is open. Make sure the cover is completely closed, then press the  button again.
- You can use the deep clean cycle even for items that don't need it. There's no harm done to the item—it just takes longer to finish the cycle.

4 Get your clean stuff



Open the cover of the XL Pro. Remove the items you placed inside – they're safe to use now!

Tour of the XL Pro



The **UV button** starts the sanitization process once the top is closed. You can choose the standard cycle (press) or deep clean cycle (press and hold). The UV button turns blue during sanitization and turns off when the sanitization cycle is complete. It flashes red if the cover is open when you try to start sanitization.

The **charging indicators** show the charging status of the devices connected to the charging ports inside the XL Pro—red while charging and green when the device charged.

The **sanitization bay** is where you put the items you want to sanitize. Once you've closed the top and pressed the UV button, items that are in the bay will receive a bath of UVC rays that kill bacteria and viruses.

The **charging ports** charge your mobile device when the XL Pro is plugged in. Just plug your charging cable in to one of the ports—your device charges both when the XL Pro is sanitizing and when it's not.

About UV sanitizing

Ultraviolet (UV) light is invisible to the human eye. The UVC part of the UV spectrum is proven to have germicidal benefits, killing bacteria and deactivating viruses. It is important to use the product with appropriate safeguards and follow safety precautions.

UV light is most effective on hard, non-porous surfaces such as phones, most phone cases, keys, credit cards, etc. UV light is less effective against fabrics and other porous materials because of the many shadows they create that may block the UV light from hitting the surface. The UV light can only kill germs on surfaces with which it comes in contact.

For more information, visit [surface-clean.com](https://www.surface-clean.com)